

## INSTALLATION

1. Turn off the valve at the base of the wall as

shown in Step 1.

2. Flush your toilet to drain the water from your

toilet tank

3. Disconnect the hose at the underside of the

toilet tank.

Step 1:



5. Install the T fitting as shown in Step 2.

Step 2:



**6. Attach the valve to the outlet end of the T**

**fitting as shown in Step 3. Wrap the threads**

**using the teflon tape**

Step 3:



7. Using the fastening set, insert the hanger at

a convenient height within easy reach as show

in Step 4.

Step 4:



**8. Connect the hose to valve by placing the rubber gasket between the nut and the valve.**

**Tighten well.**

**9. Attach the hose to rinsing spray body. Be**

sure to insert the rubber gasket. In some cases  
  
two gaskets will be required, depending on  
  
the hand bidet.

10. Test the rinsing spray to ensure there is no

**leakage.**

**Each unit is provided with a shutoff valve. The**

**valve must be turned off when not in use. In**

**addition, this will allow you to regulate the**

**pressure for your comfort and safety.**